
HOSHIZAKI





*We reserve the right to make changes in specifications and design without prior notice.

- 1. Install the ice maker properly in accordance with the instructions on location, water supply/drain connections and electrical connections stated in the instruction and installation manuals provided.
- 2. The ice production depends on the ambient and water temperatures. Refer to the instruction manual.
- 🕸3. Use a coolimg tower for cooling water.
- 34. Product Code: F083-C121

F083-C123(SB Type)

)		R		
ICE DISCHARGE HOLE (BOTTOM)(154 x 79)	+	4	4022 AR√	340 266
	281	Û AIR	(17	





	<u>DRAIN O</u>	OUTLET Rc3/8 47 (Cond.) 35
r 		WATER SUPPLY INLET G3/4 (ICE MAKING WATER)
	(12)	2 2 2 3 2 170 770
	(29)	622 622 622 751
,		Y INLET Rc1/2 (Cond.) 09
	DRA	AIN OUTLET R3/4